

SAFTRON

EXERCISE / SAFETY GRAB BARS / TOWEL BARS

Installation instructions:

Can attach to concrete, marcite pool walls, or installed outside pools to any suitable surface and used as grab bars, door handles or towel bars.

Notes:

- Non-conductive material does not require grounding.
- Kits include all necessary hardware for 15 minute installation.
- Grab Bars will only be as rigid and secure as the supporting foundation. Before installing make sure surface is suitable.
- Avoid scratches. Keep Ex-Bars in box until ready to install. Don't place Ex-Bars on bare ground.

Installation Instructions



1. Mark post locations.



2. Use mounting to caps to mark centers.



3. Drill hole in masonry with provided bit to depth of 2, 1/2".



4. Clean hole and insert anchors.



5. Firmly attach mounting caps with provided lag bolts and washes.



6. Apply adhesive to inside surface of safety/exercise bar.



7. Tap safety/exercise bar onto mounting caps.



8. Wait 30 minutes then
ENJOY!

CAUTION: Safety rails should be installed by licensed contractor. If self-installing, make sure pool is empty or use a battery operated drill. Never use A/C powered tools near water.

Saftron Manufacturing, LLC · Phone (305) 233-5511 · Fax (941) 751-2802 · www.saftron.com · info@saftron.com